



H617

NET
CONTENTS



H617 POWER-MAX2 is designed for use in Distribution Cabinets, Chase Lines and Water Treatment rooms to remove yellow and rust colored stains resulting from Bi-Carb Machines and the Water Treatment Process. It quickly removes lime, rust, calcium, scale and hard water deposits from a variety of acid-resistant hard surfaces. Product may be applied by brush, spray or as a dip tank solution.

H617 POWER-MAX2 features Earth Smart® Acid Technology:

- That dissolves calcium carbonate scale two to three times faster than phosphoric acid products.
- That is much milder to steel, aluminum and skin than traditional acids used in descaling products.
- That is phosphate-free and contains no VOCs.

DIRECTIONS FOR USE:

GENERAL PURPOSE CLEANING AND DESCALING for Distribution Cabinets, Chase Drains and Water Treatment Rooms in Dialysis Clinics:

Dilute with 1 to 10 parts of water depending upon soil and scale to be removed. Soak for 3 to 10 minutes. Rinse thoroughly with clean water.

FOR GENERAL USE AS A RUST REMOVER ON ACID-RESISTANT SURFACES:

Dilute with 1 to 10 parts of water depending on density of rust stain to be removed. Test in an inconspicuous area prior to large application to assure the product will not attack the surface. Soak for 3 to 60 minutes. Rinse thoroughly with water.

TO REMOVE SCALE IN DISHWASHING MACHINES: Apply 1/2 to full strength. Allow 5 to 10 minutes of contact and then run machine through 2 rinse cycles.

TO REMOVE SCALE AND HARD WATER DEPOSITS FROM ICE MAKERS: Dilute with 5 to 10 parts water. Soak parts and surfaces until clean. Rinse thoroughly with clean water.

TO REMOVE SCALE AND BUILD-UP FROM POTS, PANS, COFFEE URNS, ETC.: Soak items to be cleaned in solution of 6 to 10 oz. of **H617** per gallon of water for 10 to 15 minutes. Rinse thoroughly with clean water.

TO REMOVE HARD WATER DEPOSITS, SCALE AND SOILS FROM DRINKING FOUNTAINS AND HOSPITAL EQUIPMENT:

Vary dilutions based on the type and amount of deposits. Always rinse thoroughly with clean water.

POWER-MAX2

Chase Drain and Water Equipment Descaler

DIRECTIONS FOR USE: (continued)

TO CLEAN AND DESCAL WATER METERS AND FILTERS: Do not dilute. Soak until clean. Rinse thoroughly with clean water.

When used as directed, **H617 POWER-MAX2** will not harm nickel plated parts.

DO NOT USE PRODUCT IN THREE STAGE ARTIFICIAL KIDNEY (HEMODIALYSIS) MACHINES.

Do not use this product on marble.

Food contact surfaces are to be rinsed with potable water after use of this product.

WARNING: Can cause serious eye irritation. Can cause mild skin irritation. May be harmful if swallowed.



Do not breathe fume/gas/mist/vapors/spray. Wash face, hands and any exposed skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a poison center or doctor/physician. **IF ON SKIN (or hair):** Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. **IF INHALED:** Remove victim to fresh air and keep at rest in a position comfortable for breathing. Immediately call a poison center or doctor/physician. **IF SWALLOWED:** Rinse mouth. Do not induce vomiting. Immediately call a poison center or doctor/physician.

Store according to local, regional, national, and international rules and regulations. Dispose of contents/container in accordance with local, regional, national, and international rules and regulations.

CONTAINS (CAS#): Trade Secret (Proprietary)

An SDS for this product is available on HES's website. Please read the SDS carefully and follow all directions when using or handling this product. Never reuse empty containers. Incompatible materials may adversely react.

WARNING
KEEP OUT OF REACH OF CHILDREN.



Manufactured and Sold Exclusively by:
HES Healthcare Environmental Solutions
320 37th Avenue • St. Charles, IL 60174
1-800-654-1692 • HealthEnviroSolutions.com

